

# HOME DECORATORS COLLECTION


BF-25217 MARTHA STEWART LIVING KIDS CRAFT ARTWORK 31"Hx33"Wx20"D

INV#19046

## ASSEMBLY INSTRUCTIONS













Made In China



















THIS ITEM MUST BE ASSEMBLED BY AN ADULT





















Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.


IMPORTANT NOTE: Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.

PARTS LIST		
<b>A</b>  TOP PANEL-1PC	<b>B</b>  LEFT SIDE PANEL-1PC	<b>C</b>  RIGHT SIDE PANEL-1PC
<b>D</b>  BOTTOM PANEL-1PC	<b>E</b>  UP BACK PANEL-1PC	<b>F</b>  DOWN BACK PANEL-1PC
<b>G</b>  ADORNING PANEL-1PC	<b>H</b>  UP ACROSS PANEL-1PC	<b>I</b>  DOWN ACROSS PANEL-1PC
<b>J</b>  LEFT DOOR-1PC	<b>K</b>  RIGHT DOOR-1PC	<b>L</b>  SMALL DRAWER PANEL FRONT-1PC

<b>M</b>  <p>LEFT SMALL DRAWER PANEL SIDE-1PC</p>	<b>N</b>  <p>RIGHT SMALL DRAWER PANEL SIDE-1PC</p>	<b>O</b>  <p>SMALL DRAWER PANEL BACK-1PC</p>
<b>P</b>  <p>DRAWER PANEL BOTTOMS-2PCS</p>	<b>Q</b>  <p>SMALL DRAWER STAND PANELS-2PCS</p>	<b>R</b>  <p>SMALL DRAWER STAND PANELS-2PCS</p>
<b>S</b>  <p>SMALL DRAWER ACROSS PANEL-1PC</p>	<b>T</b>  <p>LARGE DRAWER PANEL FRONT-1PC</p>	<b>U</b>  <p>LEFT LARGE DRAWER PANEL SIDE-1PC</p>
<b>V</b>  <p>RIGHT LARGE DRAWER PANEL SIDE-1PC</p>	<b>W</b>  <p>LARGE DRAWER PANEL BACK-1PC</p>	<b>X</b>  <p>LARGE DRAWER STAND PANELS-2PCS</p>
<b>Y</b>  <p>LARGE DRAWER STAND PANELS-2PCS</p>	<b>Z</b>  <p>LARGE DRAWER ACROSS PANEL-1PC</p>	<b>A1</b>  <p>SHELF-1PC</p>
<b>B1</b>  <p>DRAWER SUPPORT PANELS-2PCS</p>	<b>C1</b>  <p>CAM-BOLTS-29PCS</p>	<b>D1</b>  <p>CAM-LOCKS-29PCS</p>

<b>E1</b> 8mm × 5/8"  SCREWS-6PCS	<b>F1</b>  FEET-4PCS	<b>G1</b>  DOWELS-4PCS
<b>H1</b>  OUTER SLIDES-4PCS	<b>I1</b>  INNER SLIDES-4PCS	<b>J1</b> 6mm × 1/2"  SCREWS-52PCS
<b>K1</b> 8mm × 1"  SCREWS-3PCS	<b>L1</b> 5mm × 1/2"  SCREWS-2PCS	<b>M1</b>  FEMALE MAGNETS-2PCS
<b>N1</b>  LARGE MAGNET-1PC	<b>O1</b>  HINGES-4PCS	<b>P1</b>  KNOBS-6PCS
<b>Q1</b> 6mm × 1"  SCREWS-24PCS	<b>R1</b> 7mm × 5/8"  SCREWS-2PCS	<b>S1</b>  SHELF SUPPORTS-4PCS
<b>T1</b>  CAM-T00L-1PC	<b>U1</b>  HOOKS-4PCS	<b>V1</b>  PLASTIC BELTS-2PCS


**W1**



GECKOS-4PCS

**X1**


6mm × 3/4"



SCREWS-4PCS

**Y1**



7mm × 7/8"



SCREWS-4PCS




NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

NOTE: • UPON OPENING THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY, PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.




NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.

## HOW TO USE THE CAM-TOOL




NOTE: • THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS



1). ASSEMBLE THE OUTER SLIDES (H1).


- ATTACH THE OUTER SLIDES (H1) TO LEFT SIDE PANEL (B) USING 6 SCREWS (J1).



2). ASSEMBLE THE OUTER SLIDES (H1).


- ATTACH THE OUTER SLIDES (H1) TO RIGHT SIDE PANEL (C) USING 6 SCREWS (J1).






3). ASSEMBLE THE BACK PANEL(E/F).

- ROTATE 3 CAM-BOLTS(C1) INTO THE HOLES IN THE UP BACK PANEL(E).
- PLACE CAM-BOLTS(C1) INTO THE HOLES IN THE DOWN BACK PANEL(F) AND ATTACH USING 3 CAM-LOCKS (D1).




4). ASSEMBLE THE BOTTOM PANEL(F).

- ROTATE 3 CAM-BOLTS(C1) INTO THE HOLES IN THE DOWN BACK PANEL(F).
- PLACE CAM-BOLTS(C1) INTO THE HOLES IN THE BOTTOM PANEL(D) AND ATTACH USING 3 CAM-LOCKS (D1).




5). ASSEMBLE THE LEFT SIDE PANEL (B).

- ROTATE 6 CAM-BOLTS (C1) INTO THE HOLES IN THE LEFT SIDE PANEL (B).
- PLACE CAM-BOLTS (C1) INTO THE HOLES IN THE PANEL (D/E/F) AND ATTACH USING 6 CAM-LOCKS (D1).




6). ASSEMBLE THE ACROSS PANEL (H/I).

- ROTATE 2 CAM-BOLTS (C1) AND INSERT 2 DOWELS (G1) INTO THE HOLES IN THE LEFT SIDE PANEL (B).
- PLACE CAM-BOLTS (C1) INTO THE HOLES IN THE PANEL (H/I) AND ATTACH USING 2 CAM-LOCKS (D1).




7). ASSEMBLE THE RIGHT SIDE PANEL (C).

- ROTATE 8 CAM-BOLTS (B1) AND INSERT 2 DOWELS (G1) INTO THE HOLES IN THE RIGHT SIDE PANEL (C).
- PLACE CAM-BOLTS (B1) INTO THE HOLES IN THE PANEL (E/F/D/H/I) AND ATTACH USING 8 CAM-LOCKS (C1).




8). ASSEMBLE THE FEET (L).

- ROTATE 4 FEET (L) INTO THE HOLES IN THE PANEL (B/C).




9). ASSEMBLE THE ADORNING PANEL (G).

- ATTACH THE ADORNING PANEL (G) TO TOP PANEL (A) USING 3 SCREWS (K1).




10). ASSEMBLE THE TOP PANEL (A).

- ROTATE 6 CAM-BOLTS (C1) INTO THE HOLES IN THE TOP PANEL (A).
- PLACE CAM-BOLTS (C1) INTO THE HOLES IN THE PANEL (B/C/E) AND ATTACH USING 6 CAM-LOCKS (D1).




11). ASSEMBLE THE LARGE MAGNET (N1).

- ATTACH THE LARGE MAGNET (N1) TO DOWN ACROSS PANEL (I) USING 2 SCREWS (R1).




12). ASSEMBLE THE SHELF SUPPORTS (S1).

- INSERT 4 SHELF SUPPORTS (S1) INTO THE HOLES IN THE PANEL (B/C).



13). ASSEMBLE THE SHELF (A1).


- ATTACH THE SHELF (A1) TO SHELF SUPPORTS (S1) USING 4 SCREWS (J1).



#### 14). ASSEMBLE THE SMALL DRAWER.

- ATTACH SMALL DRAWER PANEL SIDE(M/N) USING 4 SCREWS(Q1).
- ATTACH 2 KNOBS(P1) TO SMALL DRAWER PANEL FRONT(L) USING 2 SCREWS(E1).
- INSERT THE DRAWER PANEL BOTTOM(P) INTO THE SLOTS IN THE SMALL DRAWER PANEL SIDE(M/N).
- ATTACH SMALL DRAWER PANEL BACK(O) BETWEEN SMALL LEFT DRAWER PANEL SIDE(M) AND SMALL RIGHT DRAWER PANEL SIDE(N) USING 4 SCREWS(Q1).
- ATTACH THE DRAWER SUPPORT PANEL(B1) TO DRAWER PANEL BOTTOM(P) USING 4 SCREWS(Q1).
- INSERT PANEL(Q/R/S) INTO THE SLOTS IN THE SMALL DRAWER.


Arrow faces drawer front



15). ASSEMBLE THE INNER SLIDES(I1).

- ATTACH THE 2 INNER SLIDES(I1) TO SMALL DRAWER PANEL SIDE(M/N) USING 6 SCREWS(J1).






#### 16). ASSEMBLE THE LARGE DRAWER.


- ATTACH LARGE DRAWER PANEL SIDE(U/V) USING 4 SCREWS(Q1).
- ATTACH 2 KNOBS(P1) TO LARGE DRAWER PANEL FRONT(T) USING 2 SCREWS(E1).
- INSERT THE DRAWER PANEL BOTTOM(P) INTO THE SLOTS IN THE LARGE DRAWER PANEL SIDE(U/V).
- ATTACH LARGE DRAWER PANEL BACK(W) BETWEEN LARGE LEFT DRAWER PANEL SIDE(U) AND LARGE RIGHT DRAWER PANEL SIDE(V) USING 4 SCREWS(Q1).
- ATTACH THE DRAWER SUPPORT PANEL(B1) TO DRAWER PANEL BOTTOM(P) USING 4 SCREWS(Q1).
- INSERT PANEL(X/Y/Z) INTO THE SLOTS IN THE LARGE DRAWER.

Arrow faces drawer front




17). ASSEMBLE THE INNER SLIDES(I1).

- ATTACH THE 2 INNER SLIDES(I1) TO LARGE DRAWER PANEL SIDE(U/V) USING 6 SCREWS(J1).




### 18). ASSEMBLE THE DRAWERS.

- INSERT 2 DRAWERS INTO THE SLIDERS.



### 19). ASSEMBLE THE DOOR(J/K).

- ATTACH 2 KNOBS(P1) TO DOOR(J/K) USING 2 SCREWS(E1).
- ATTACH 2 FEMALE MAGNETS(M1) TO DOOR(J/K) USING 2 SCREWS(L1).
- ATTACH 4 HINGES(O1) TO DOOR(J/K) USING 12 SCREWS(J1).




20). ASSEMBLE THE DOOR(J/K).

- ATTACH THE DOOR(J/K) TO SIDE PANEL(B/C) USING 12 SCREWS(J1).



# Warning

The anti-tip hardware must be used as part of assembly!



21). ASSEMBLE THE HOOKS (V1).

- ATTACH THE HOOKS (U1) TO TOP PANEL (A) USING 4 SCREWS (X1).



## 22). ASSEMBLE THE ANTI-TIP HARDWARE.

- DRILL 4 HOLES INTO THE WALL, PLEASE REFER TO THE REAR TOP PANEN'S HOLE DISTANCE AND HEIGHT.
- PUT 4 GECKOS(W1) INTO THE HOLES IN THE WALL, AND ROTATE 4 SCREWS(Y1) INTO THE GECKOS(W1).
- CONNECT THE TWO HOOKS(U1) WITH A PLASTIC BELT(V1).